Operating Instructions

FLX

Com-Center Start:

- Attach AC power cord to Com-Center, then plug into the nearest wall outlet.

- If wall outlet is not available insert rechargable battery into slot at back of Com-Center (silver contacts must be in proper position).

- OR use five brand name AA batteries in battery sled (provides up to 6 hours of operation).

- Turn Com-Center ON (switch on back panel).

Note: If rechargeable battery and AC power cord are used simultaneously, the battery will receive a trickle charge while system is in use.

Com-Center Facts:

Line of Sight

- For optimum range, position the Com-Center so that the radio signals have a clear path to the wireless headsets.

OFF/DEF/Conference Feature

- Red & Green LED lights indicate offense and defense are operational.
- Press **Conference button** for amber LED so all coaches can communicate.

Note: Headset jacks and volume controls are included to accommodate future expansion through the addition of pressbox headsets.

Wireless Headset Start:

- Insert battery into headset.
- Headset will automatically turn ON.

Note: Slide battery into compartment bottom first, then press top to snap into place. Push latch up to eject.

Blue LED Indications:

- Blue LED blinks as headset searches for signal.

- LED turns SOLID BLUE automatically when headset senses the signal from the Com-Center.

- Solid blue LED means headset is communicating.

Note: When the wireless headset LED is blinking, it means the headset is searching for the signal. When the Com-Center is ON the headset LED will automatically change to solid blue (indicating communication).

Headset Controls:

Power Button

Subsequent to performing the headset start-up procedure, the power button is used to simply turn the headset on and off.

- OFF by pressing & holding untill LED goes out.

- ON by quick clicking, LED Illuminates.

Volume

- Headset volume is set to middle level upon power-up. Volume control buttons adjust to any of five settings.

MIC Mute - grey button

- Click MIC button to mute microphone, audible tone confirms change.



Channel Switch - red button

- Included with switching headsets.

- Repetitive beep indicates headset battery low.

Battery Charging

- System includes 2 rechargeable batteries: one battery for the 1st half & one battery for the 2 half.

- Plug charger AC adapter into charging base and into wall outlet.

IMPORTANT: There are two AC adapters supplied with this system. The Com-Center adapter will fit ONLY the Com-Center.
The Charger adapter will fit ONLY the Charger.

- Batteries should snap into charging slot securely.

- Charge time 2 - 4 hours.

LED Indicators:

- GREEN:	Fully charged
- RED:	Charging
- RED Flashing:	Battery Faulty
- NO LIGHT:	Battery improperly inserted

Battery Facts

- COMSTAR high capacity Lithium batteries provide up to 10 hours of operation.

- Lithium batteries do not develop a memory. **Do not drain batteries after use.**

Important Tips

Microphone Placement

- COMSTAR headsets include a special noise cancelling microphone. For optimum performance place directly in front of, and approximately 1 - 2" from the user's mouth.

Com-Center Placement

- Line of sight: for optimum range, position the Com-Center so that the radio signals have a clear path to the wireless headset/radios.

Rain Game / Storage

- Place the Com-Center in a protected dry location during use.
- Before storing, wipe down all equipment and leave out in a well ventilated room to fully dry.
- Do not store in individual drawstring bags or carrying case while wet.

Caution

Compartment on bottom of Com-Center houses switches for factory programming. Call Porta Phone for more information: 1-800-233-1113.

User Manual

COMSTAR

Duplex Wireless System

PORTA PHONE
145 Dean Knauss Drive
Narragansett, RI 02882
Tel: 1-800-399-5994
In RI: 401-782-4966
Fax: 401-789-7300
www.eartec.com

FLX